

International specifications Stromtank S2500

Input AC parameters on grid

Input voltage range 50 to 140 Vac / 150 to 265 Vac

Input frequency 45 to 65 Hz (auto sensing)

Input current max. 16 Aac (transfer relay)

Input current adjusted 10 Aac (115Vac), 10 Aac (230Vac) – factory setting

transfer time < 15 ms, on grid to off grid

Output AC parameter off grid

Output voltage 100-130Vac / 200-245Vac (pure sine wave +/- 2%)

Output frequency 50 Hz / 60 Hz +/- 0.05% (crystal controlled)

Harmonic distortion < 2%

Continues power @ 25°C 600 VA

Power 30min. @ 25°C 1.000 VA

Maximum load up to short circuit

Maximum asymmetric load up to P cont.

Load detection (Stand by) 10 W $\cos \varphi$ 0.1 - 1

Maximum efficiency 93% (dc/ac conversion mode)

Consumption stand-by/on 1.5 W / 8 W

Overload + short-circuit protection automatic disconnecting with 3 restart attempts

Overheat protection warning before shut-down with automatic restart

Operating temperature +10 to 45°C

Relative Humidity 0 to 85% non- condensing

Acoustic level < 40 dB

Battery power unit

Battery type LFP - Lithium Iron Phosphate (LiFePO4)

Nominal battery voltage 24 Vdc

Nominal capacity 100 Ah

Volume Energy Density 177 Wh/l

Gravimetric Power Density 107 Wh/kg



Typical charge current 8 Adc - factory setting Working temperature 0 to 45°C, 32 to 113°F

Emergency charge current 3 Adc (special STROMTANK charger necessitated)*

Battery Management System Flex-BMS, single cell control, active balancing 5A

Terminal area

AC output receptacles 3x Hubbell duplex, Hospital spec. grade

3x Furutech High performance Schuko sockets

AC output fuse thermal – magnetic circuit breaker
AC input connection ICE 320 - C14 (fuse 16/10AT)

Interface CAN (RJ45-8 type "Com bus")*, USB*

Charge connector use STROMTANK charger only

Power switch on/off ("on" = green LED)

Safety key switch key switch "Release/Lock" all functions**

Additional Features

Color meteorit-gray (other colors on request)

Weight 61 kg / 134 lbs

Dimension (w x h x d) 48 x 45 x 30 cm / 19 x 17 x 12 inches

** ATTENTION

You have to switch **off** STROMTANK with the "power switch" before locking. You have to unlock before switch **on** STROMTANK.

We provide the following limited warranty (detailed information look warranty regulations):

3 years for electronical parts, battery cells, inverter and BMS



This symbol indicates the presence of a dangerous voltage that is sufficient to constitute a risk of electric shock.



Only "STROMTANK compatible accessories and devices can be connected to the RJ45-8 connectors, excluding any other connections such as LAN, Ethernet, ISDN or other. Connecting a non-compatible device may cause serious damage not covered by the manufacturer's warranty.

^{*} only for use with "STROMTANK" software and charger